Aqua Light GmbH

Mini ATO Bedienungsanleitung

GB

Function

1. **Automatic refilling**
   The Aqua Light mini ATO automatically refills the aquarium water as soon as it drops below the sensor minimum. The controller switches on the pump and automatically switches it off again as soon as the required water level is attained, hence maintaining your aquarium water at a constant level.

2. **Overfill protection**
   Most mechanical sensors are susceptible to failure and lead to overfilling. Our mini ATO is equipped with an overflow protection which ensures that your tank never overflows. This additional safety feature makes our product extremely reliable especially when the user is not home for a while.

Installation

1. Mount the mini ATO on the fish tank wall with the magnetic holder. Place the sensor at the position of the required water level.
2. Connect the pump to the controller and place it in the reservoir/backup tank.
3. Make sure there is sufficient water in the tank.
4. Connect the hose to the water pump and install it in the fish tank using the hose clip.
5. Connect the power supply and test for functionality by slowly sliding the sensor above water level until the pump switches on. Slide it down again to make sure the pump switches off.





Caution:

- Place the outlet of the hose higher than the aquarium water level to avoid the siphon effect.
- Do not install the sensor in an area with air bubbles, direct sunlight, or strong water movement. This might affect the accuracy of the sensor.
- Make sure you create a drip-loop to avoid water running into the power supply
- Make sure the sensor is always free from dirt. This will guarantee accuracy.
- Use the device only with the original power supply and accessories.

Limited warranty:

Aqua Light GmbH offers a 12-month limited warranty on this device beginning at the day of purchase by the consumer. This does not apply to wear parts like hoses, pump heads and motors. Note that a valid proof of purchase is required to claim warranty. Claims without proof of purchase will not be accepted.

DE

Funktion

1. Automatisches Nachfüllen

Der Aqua Light mini ATO füllt das Aquarienwasser automatisch nach, sobald es unter das Sensorminimum fällt. Die Steuerung schaltet die Pumpe ein und wieder automatisch aus, sobald der erforderliche Wasserstand erreicht ist, wodurch Ihr Aquarienwasser auf einem konstanten Niveau bleibt.

2. Überfüllschutz

Die meisten mechanischen Sensoren sind störanfällig und führen zu Überfüllung. Unser Mini-ATO ist mit einem Überlaufschutz ausgestattet, der sicherstellt, dass Ihr Aquarium niemals überläuft. Diese zusätzliche Sicherheitsfunktion macht unser Produkt äußerst zuverlässig, insbesondere wenn der Benutzer eine Weile nicht zu Hause ist.

Installation

1. Montieren Sie den Mini ATO mit dem Magnethalter an der Wand des Aquariums. Stellen Sie den Sensor an die Position des gewünschten Wasserstandes.

2. Schließen Sie die Pumpe an die Steuerung an und stellen Sie sie in den Vorratsbehälter.

3. Stellen Sie sicher, dass sich genügend Wasser im Vorratsbehälter befindet.

4. Schließen Sie den Schlauch an die Wasserpumpe an und installieren Sie ihn mit dem Schlauchhalter im Aquarium.

5. Schließen Sie das Netzteil an und prüfen Sie die Funktionalität, indem Sie den Sensor langsam über den Wasserspiegel schieben, bis sich die Pumpe einschaltet. Schieben Sie es wieder nach unten, um sicherzustellen, dass die Pumpe abschaltet.

Achtung:

• Platzieren Sie den Schlauchauslass höher als den Wasserstand im Aquarium, um den Siphon-Effekt zu vermeiden.

• Installieren Sie den Sensor nicht in einem Bereich mit Luftblasen, direkter Sonneneinstrahlung oder starker Wasserbewegung. Dies kann die Genauigkeit des Sensors beeinträchtigen.

• Stellen Sie sicher, dass Sie eine Tropfschleife erstellen, um zu vermeiden, dass Wasser in die Stromversorgung reinfließt.

• Stellen Sie sicher, dass der Sensor immer frei von Schmutz ist. Dies garantiert die Genauigkeit.

• Verwenden Sie das Gerät nur mit dem Originalnetzteil und Zubehör.

Eingeschränkte Garantie:

Die Aqua Light GmbH gewährt auf dieses Gerät eine beschränkte Garantie von 12 Monaten ab dem Tag des Kaufs durch den Verbraucher. Dies gilt nicht für Verschleißteile wie Schläuche, Pumpenköpfe und Motoren. Beachten Sie, dass ein gültiger Kaufnachweis erforderlich ist, um die Garantie zu beanspruchen. Ansprüche ohne Kaufnachweis werden nicht akzeptiert.

Aqua Light GmbH
Am Basterpohl 6,
49565 Bramsche
www.aqualight.de

WEEE-DE14852969